

Design Guidelines

In Washington Grove

Varied roof lines and pitches



Roof planes
broken via
multiple
dormers.



Use of porches
to break up bulk.



Low eave lines
used to reduce
scale.



Wall Planes
Broken via Use of
Bays and/or
indentations.



Placement of
additions
away from
Front

